



INSTRUCTIONS:
PRINT ON A3 PAPER AND CHECK THE SCALE BY MEASURING THE 50.0mm LINE
GLUE TO STIFF CARBOARD AND CUT OUT PROFILE
INSERT THE PROFILE INTO THE WHEEL SPIGOT UP TO THE MOUNT FACE
CHECK THAT THE EDGE OF THE PROFILE DOES NOT TOUCH THE INSIDE OF THE WHEEL
AT ANY POINT AROUND THE INNER CIRCUMFERENCE

-REMOVE ALL SHARP EDGES AND
BURRS UNLESS OTHERWISE STATED
-ALL INTERNAL CORNERS TO BE
R0.8 UNLESS OTHERWISE STATED
MASS = 0.000 kg (at 2.700 S.G.)

0	-	-	FOR PRODUCTION			S.C.	26-Jun-25		
ISSUE	ECN #	SYM	REVISIONS			DRN	DATE	CHK	DATE
			HARROP ENGINEERING AUSTRALIA PTY. LTD. 96 BELL ST PRESTON, 3072 VICTORIA, AUSTRALIA Ph. (613) 9474-0900 Fax. (613) 9474-0999		COPYRIGHT APPLIES <i>Duplication of this drawing or any specific design features is not permitted without written authority. "Commercial Confidentiality" is assumed and required.</i>		UNSTATED TOLERANCES		
							LINEAR		
							0 ± 0.25		
							0.0 ± 0.1		
							0.00 ± 0.05		
							ANGULAR		
							0.0 ± 0.5°		
							0.00 ± 0.05		
			SWEEP, BRAKE KIT, FRONT, FORD BF-FG, 381, BOBBIN DRIVE, FMB						
			FILE ..\SWEEP_BRK-KIT_FRT_FMB.A15966						
			DRAWING						
			A15966-0						
MATERIAL AS SUPPLIED			Pro/ENGINEER DIGITAL DATA AVAILABLE						
FINISH AS MACHINED			SCALE 100 ON A3		SHEET 1 OF 1				